


※別売りの「NB-019 ナノブロック専用ピンセット」を使うと組み立て、取りはずしに便利です。
Use "NB-019 nanoblock® Tweezers" (sold separately) for an easy way to assemble and disassemble blocks.




本製品は電池・USB 両方の電源に対応しております。/ This product can be used with both battery and USB power supply.
正しくご利用いただくため、本取扱説明書をよくお読みください。/ Please read this instruction manual carefully before use.
※本製品は充電式ではありません。/ ※ This product is not rechargeable.

電池交換の方法 / How to replace batteries

1. 図の様にプラスドライバーを使ってネジを外し、電池ボックスのフタを開けてください。
2. 図のように正しい方向で単4アルカリ電池を3本セットしてください。
3. 電池ボックスのフタを閉め、ネジでしっかりと留めてください。
4. 本体側面のスイッチを「BATTERY」(電池)にセットするとLEDが点灯します。
※USB使用時は必ず電池を抜いてご使用ください。


1. Remove the lid of the battery housing with a screwdriver as shown in the Figure.
2. Insert 3xAAA batteries properly as shown in the Figure.
3. Replace the lid of the housing and tighten the screw.
4. The LED light turns on when the switch on the side of the body is flipped to "BATTERY".
※Remove the battery when using USB mode.



BATTERY WARNINGS

- Do not mix old and new batteries or different type of batteries.
- Insert batteries with the correct polarity.
- Do not use rechargeable batteries (nickel-metal hydride batteries, nickel-cadmium batteries).
- If the electrolyte leakage from the battery gets into your eyes, immediately rinse with plenty of water and seek medical advice.
- If the electrolyte contacts your skin or clothing, immediately wash with water.
- Do not place near heaters, stoves, and other heat sources.
- Do not heat or put in water or fire.
- Stop using the batteries immediately when they get wet with water. It can cause the batteries to short out.
- For environmental protection, sort out the exhausted batteries and electric parts when disposing.
- Rechargeable batteries are not to be recharged.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.

USB 電源の使用法 / How to use the USB power



1. 市販のUSB ケーブル (別売) ※1 を使用して、パソコンと接続します ※2。
 2. 本体側面のスイッチを「USB」にすることでLEDが点灯します。
- ※1 USB (Micro-B) オス - USB (A) オスのケーブルをご使用ください。
※2 電池使用時は本体からケーブルを抜いてご使用ください。
※3 USB ハブ等に複数の機器を接続した場合、LEDの輝度が低下する場合があります。

警告 (けいこ)

- 使用中、発熱、発煙、発火、変形などが発生した場合、すぐパソコンやコンセントから取り外してください。
- 短絡したり、分解したり、水や火のそばに置かないでください。
- 故障時修理しない場合は、パソコンやコンセントから取り外し、電源を取り出して保管してください。
- ケーブルの両端の挿入方向が逆で、ケーブルが壊れる場合があります。ケーブルの両端の挿入方向を確認してください。
- 接続しているUSBケーブルは、必ず両端がしっかりと接続されていることを確認してください。
- 接続ケーブルは、必ず両端がしっかりと接続されていることを確認してください。
- 接続ケーブルは、必ず両端がしっかりと接続されていることを確認してください。
- 接続ケーブルは、必ず両端がしっかりと接続されていることを確認してください。

注意 (ちゅうい)

- 変形の恐れがありますので、火気の近くや湿気の多いところなどでの使用や保管は避けてください。
- ケーブルの両端を、必ずしっかりと接続してください。ケーブルの両端を、必ずしっかりと接続してください。
- 本体が変形した状態での使用はおやめください。

完成!
Finished!



※部品は多めに入っております
Extra blocks included

※本商品には、USB ケーブルは付属しておりません。
注意表記をご確認ください。接続に合ったケーブル
をご使用ください。
※ USB cables are not included in this product.
Read the safety instructions and use cables which
meet the standards.

1. Using commercially available USB cables (sold separately) ※1, connect the LED plate to a computer. ※2
2. The LED light turns on when the switch on the side of the body is flipped to "USB".

- ※1 Please use the USB (Micro-B) male - USB (A) male cable.
※2 Please unplug the USB cable from the LED plate during battery use.
※3 The LED brightness may decrease when several devices are connected to the same USB hub.

WARNING

- Immediately unplug the product from the computer or power socket if excessive heat, smoke, unusual odor emanates from the product or if there is any deformation during use.
- Do not heat, disassemble, or put in water or fire.
- When not using for a long period, unplug the product from the computer or power socket and remove the batteries for storage.
- Do not light the product near anyone's eyes. It can cause eye damage or accidents.
- Do not use damaged USB cables.
- Do not apply excessive force when the cable is connected to the unit.
- Do not let conductive objects, such as metal pieces, touch or put in the USB port.
- For environmental protection, sort out the exhausted electric parts when disposing.

CAUTION

- Avoid using or storing the product near fire or in high humidity. It can cause deformation.
- When plugging in/out the cable, hold the base of the plug horizontally and do not apply excessive force.
- Do not use when the unit is damaged.